
DISPLAY UNIT

Stock number: 304X-22

Thank you for purchasing this product. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product.

Necessary Tools: Pozi screwdriver



Ph 2



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product takes approximately 45 MINUTES to assemble with 3 PEOPLE.


All assembly should be performed on a flat, stable, clean and soft surface.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product

The fitting pack contains SMALL ITEMS which should be KEPT AWAY FROM YOUNG CHILDREN.

IMPORTANT: Retain these instructions for future reference.

Page: 1



Fittings and parts checklist

ltem	Description			Qty.	ltem	Description		Qty.
1	Top unit			x 1	3	Leg frame		x 2
2	Front rail			x 2				
Α	Wooden dowel Ø8 x30mm			x 8	D	Grub screw M8 x 8mm	9 .	x 4
В	Steel dowel Ø 7 x 52mm			x 4	Е	Allen key M4 x 30 x 110mm		x 1
C	Housing Ø15 x 13.5mm			x 4	F	Hex head bolt M6x60mm Ø12		x 8

Page: 2

Step By Step Assembly Instructions

Step


(1)

- 1.1: Lay all parts on a flat, stable, clean and soft surface.
- 1.2: Insert 8x wooden dowels (A) into the pre-drilled holes on parts (2) as shown.
- 1.3 : Attach 4x steel dowels (B) to leg frame (3) by screwing fittings (B) into the inset fittings that are located on part (3) as shown. Use a pozi screwdriver to turn fittings (B) clockwise to fix.


Fitting

8 x A

Bx4




Step By Step Assembly Instructions



Step 2.3


Step By Step Assembly Instructions



HINGE ADJUSTMENT INSTRUCTIONS


LATERAL ADJUSTMENT

by screw adjustment.




FRONT-TO-BACK

by slackening and retightening the hinge-arm mounting screw.



VERTICAL ADJUSTMENT

via slots on mounting plate by slackening and retightening the screws on mounting plate



Page:6

16/09/24 July 79/4